

QUESTIONS OR CONCERNS CONTACT AT:
1-800-265-1833 (English) / 1-800-567-2513 (French)
Monday through Friday 8:00 AM to 5:00 PM E.S.T.



INSTRUCTIONS PERTAINING TO RISK OF FIRE OR INJURY TO PERSONS
READ ALL INSTRUCTIONS

IMPORTANT SAFETY INSTRUCTIONS

SAVE THESE INSTRUCTIONS

TOOLS AND MATERIALS REQUIRED:



Pliers



Wrench


Wiring supplies as required by
local electrical code

SAFETY PRECAUTIONS:

1. **TURN OFF ELECTRICAL POWER BEFORE STARTING INSTALLATION OF LIGHT FIXTURE.**
2. **THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.**
3. **NOTICE: THE MAXIMUM DISTANCE TO THE ELECTRICAL OUTLET IS DETERMINED BY THE LENGTH OF POWER SUPPLY CORD.**
4. **WHEN SUSPENSION MOUNTING, MAKE SURE THE LIGHT FIXTURE IS LOCATED DIRECTLY BELOW THE ELECTRICAL OUTLET. EXCESS CORD SHOULD BE SECURED TO THE MOUNTING CHAIN WITH THE CABLE TIE PROVIDED.**
5. **TO CLEAN THE FIXTURE, TURN OFF THE POWER, WAIT FOR IT TO COOL, AND WIPE THE FIXTURE WITH A CLEAN, SOFT CLOTH.**

NOTE: Product may not look exactly as shown in figures.


INSTALLATION:



1. Secure the two open screw eyehooks (provided) to the ceiling 18 1/4" apart. Secure directly to a joist or using toggle bolts (not included).

2. Attach the mounting chains (provided) to the open screw eye hooks.

3. Attach the mounting chain to the fixture. Crimp the screw eye hooks closed using pliers.



4. Level the fixture by adjusting the length of the chain at the open screw eye hooks. Crimp the screw eye hooks closed using pliers.

5. Install specified bulb type and wattage.

6. Plug in and pull chain down to turn on.

QUESTIONS OU INFORMATION COMMUNIQUE AVEC AU:

1-800-265-1833 (Anglais) / 1-800-567-2513 (Français)

Du lundi au vendredi entre 8:00H et 17:00H H.N.E.



INSTRUCTIONS CONCERNANT LE RISQUE
D'INCENDIES OU LES DOMMAGES CORPORELS
LISEZ TOUTES LES INSTRUCTIONS

INSTRUCTIONS DE SÛRETÉ IMPORTANTES GARDEZ CES INSTRUCTIONS

OUTILS ET MATERIAUX REQUIS:



Pinces



Clef


Fournitures électriques telles que
prescrites par les normes locales

MISE EN GARDE:



- 1. FERMER LE COURANT AU DISJONCTEUR AVANT DE DÉBUTER L'INSTALLATION DE LA FIXTURE.**
- 2. CE PRODUIT DOIT ÊTRE INSTALLÉ SELON LE CODE D'INSTALLATION PERTINENT, PAR UNE PERSONNE QUI CONNAIT BIEN LE PRODUIT ET SON FONCTIONNEMENT AINSI QUE LES RISQUES INHÉRENTS.**
- 3. AVIS: LA DISTANCE MAXIMALE À LA PRISE ÉLECTRIQUE EST DÉTERMINÉE PAR LA LONGUEUR DU CORDON D'ALIMENTATION.**
- 4. LORSQUE QU'INSTALLÉ EN SUSPENSION, ASSUREZ-VOUS QUE LE LUMINAIRE EST SITUÉ DIRECTEMENT SOUS LA PRISE ÉLECTRIQUE. LE SURPLUS DE CORDON DOIT ÊTRE FIXÉ À LA CHAÎNE À L'AIDE DE L'ATTACHE-CÂBLE FOURNI.**
- 5. POUR NETTOYER LE LUMINAIRE, L'ÉTEINDRE, ATTENDRE QU'IL SOIT FROID, PUIS LE NETTOYER AVEC LINGE PROPRE ET DOUX.**

N.B.: Peut différer de illustration.


INSTALLATION:




1. Posez les deux vis à oeillet (fournies) au plafond à une distance de 18 1/4" entre elles. Posez directement sur une solive ou à l'aide d'ancres à placoplâtre (en sus).




2. Posez les chaînes de montage (fournies) zux vis à oeillet ouvertes.



3. Posez la chaîne d'installation au luminaire. Fermez les vis à l'aide de pinces pour sécuriser le tout.



4. Mettre la fixture de niveau en ajustant la longueur de la chaîne aux ouvertures sur les vis à oeillet. Fermez les vis à l'aide de pinces pour sécuriser le tout.



5. Posez l'ampoule de type et de wattage requis.

6. Branchez et tirez la chaîne pour l'allumer.